

Quand il y a un «0» dans la case c'est qu'il faut couper le fil

CTMULTILEAD.5 - INSTALLATION MANUAL

Configuration Assignments (1 = Link Made, 0 = No Link)

J1	J2	J3	J4	Systems	Connector
1	0	0	1	JVC	Jack (old), Key1(new)
0	1	0	1	BEAT/Philips/Nakamichi	Key1
1	1	0	1	Clarion	Jack
0	0	1	1	Kenwood	Key1
1	0	1	1	Alpine	Jack
0	1	1	1	Panasonic	Key1
1	1	1	1	Sony/LG/Pioneer	Jack
1	1	1	0	Pioneer (Type 2)	Jack
1 (Pin12)	1 (Pin10)	0	1	Zenec	Key1
1	1	1	1	Chinese Learning Brands	Key1, Key2, GND
0	1	0	1	Grundig	Key1

Pin	Description	Colour
1	Not populated	N/A
2	Not populated	N/A
3	Not populated	N/A
4	Analog 2 SWC	Grey
5	Ground SWC	Black
6	Analog 1 SWC	Brown/White
7	Link J3	Purple
8	Link J3	Purple
9	Link J2	Green
10	Link J2	Green
11	Link J1	Orange
12	Link J1	Orange

12	10	8	6	4	2
11	9	7	5	3	1
J1	J2	J3			

Examples of lead configurations:

ALPINE - Cut connection between **J2**, then use the **Jack** connection for the new stereo.

KENWOOD: Cut connections between **J1** and **J2**, then use the wired connections for the new stereo.

ZENEC - Cut the connection between **J1**, **J2** and **J3**. Solder together the wires from **Pin 10 (J2)** and **Pin 12 (J1)**. Then use the wired connections for new stereo.

